

Installation procedure OCS Silt Screens

Step 1 : Fold out fabric which is on roll and face all towards water.



Step 2 : Put floats into upper tube. Always put 0,5 metre less foam length into the tube length.



Step 3 : Close end caps with shackles and connect blue band to yellow loop of horizontal tension band below floater.



Step 4 : Pull ballast chain into chain channel below floater, ropes are in already. Fit optional marker lights.



Step 5 : Connect sections (if needed) towards each other with shackle at same yellow loop band.



Step 6 : Connect (if needed) vertical fabric with steel grommets of each section using ty-wraps or rope.



Step 7 : Make sure before bringing system in the water that the skirt is bonded upwards to floaters by ropes every 2-3 mtrs.



Step 8 : Bring system slowly into the water, use yellow tension band loop when pulling into the water !!



Step 9 : At location make anchoring first and only when all is OK, then relieve ropes so skirt will fall down.



Note:

We sell many types of Silt Screen systems, manufactured from all kind of materials. Above pictures may not be exactly what you have purchased and is for guiding only.